



EZS40

NO. PART NAME							
1	BODY	18	TRIP PLUNGER	31	ROTOR NUT SCREW	44	CLICK GEAR
2	N-R PAWL	19	BAIL ARM SPRING	32	O/S SLIDER PLATE	45	SHEET WASHER
3	"E" WASHER	20	BAIL ARM COVER	33	SCREW	46	SPOOL ASSEMBLY
4	N-R LEVER	21	SCREW	34	O/S GEAR	47	LINING WASHER
5	N-R LEVER SHAFT	22	BAIL ARM	35	O/S SLIDER	48	SPOOL WASHER
6	N-R LEVER SCREW	23	BAIL ARM SCREW	36	MAIN SHAFT	49	DRAG WASHER
7	N-R LEVER SPRING	24	BAIL WIRE ASSEMBLY	37	O/S SLIDER SCREW	50	STOP RING
8	PINION	25	LINE ROLLER BUSHING	38	DRIVE GEAR	51	DRAG KNOB ASSEMBLY
9	PINION BUSHING	26	LINE ROLLER	39	WASHER	52	REAR COVER
10	SCREW	27	LINE ROLLER WASHER	40	BUSHING	53	REAR COVER SCREW
11	N-R SPRING HOLDER	28	L-ROLLER SCREW	41	BODY COVER	54	HANDLE ARM ASSEMBLY
12	N-R SPRING	29	ROTOR NUT	42	COVER SCREW		
15	ROTOR ASSEMBLY	30	ROTOR NUT WASHER	43	COVER SCREW		